

LED8 Customer Display Test Method

Notice: Please ensure the port for customer display was not used by other programs before measuring.

1. Open the file  to find the customer display program .
2. Choose the port for customer display on the pop-up window, COM2 is for built-in port and COM1 is for external port. After the port selection, then click "AutoDemo", it will enter into automatic demonstration interface.

